



Templates & Stick-On Decals

Instructions for using Templates & Stick-On Decals


- Cut out top and side templates along dotted line.




- Place side template against the side of block making sure the axle notches match those on the template.
- Trace around the edge to form the profile of your car. Repeat on the other side.




- Place top template on top of car and trace.
- Following car kit instructions, cut out the shape of your PineCar Racer.



- Paint car with PineCar paints.




- Cut out decals with scissors.
- Test place them on your car.




- When satisfied peel backing off and place decal on your PineCar Racer.

Instructions pour les calibres employants et Bâton-Sur des décalques


- Calibres supérieurs et latéraux coupés suivant la ligne pointillée.




- Placez le calibre latéral contre le côté du bloc en s'assurant l'allumette d'entailles d'axe ceux sur le calibre.
- Tracez autour du bord pour former le profil de votre voiture. Répétez de l'autre côté.




- Placez le calibre supérieur sur la voiture et tracez.
- Après des instructions de kit de voiture, coupez la forme de votre Racer de PineCar.



- Peignez la voiture avec des peintures de PineCar.



- Décalques coupés avec des ciseaux.
- Examinez les placent sur votre voiture.



- Quand décalque satisfait de dégagement et d'endroit de peau sur votre Racer de PineCar.