

PineCar Dry Transfer Decals are the quickest and easiest way to customize your racer. Here's all you need to do:



- Apply to a clean, dry, dust-free surface only. Position decal and hold carrier sheet firmly in place.
- Rub with burnisher or dull pencil. Do not rub too hard when transferring.
- Lift carrier sheet. If transfer was incomplete, let sheet fall back into place and transfer remainder.
- Place backing paper over decal and reburnish.

- 
- Appliquer uniquement sur une surface propre, sèche et sans poussière. Mettre en place la décalcomanie et tenir la feuille de transport fermement en position.
  - Frotter avec un brunissoir ou un crayon émoussé. Ne pas frotter trop fort pendant le transfert.
  - Soulever la feuille de transport. Si le transfert est incomplet, laisser la feuille retomber en place et effectuer le reste du transfert.
  - Placer le papier protecteur sur la décalcomanie et brunir à nouveau.

---

### HINTS AND SUGGESTIONS

- For maximum durability apply a very light coat of gloss. Allow to dry thoroughly between coats. **NOTE:** Test on small area before applying to entire racer.
- Stripes can be cut shorter or transferred end to end for longer stripes.

### CONSEILS ET SUGGESTIONS

- Pour une durabilité maximale, appliquer une couche très légère de brillant. Laisser sécher complètement entre les couches.
- Les rayures peuvent être coupées courtes ou transférées l'une derrière l'autre pour des rayures plus longues.