


## BETTY'S BURNING BUILDING BR5051

Betty's Burning Building contains an interior set of LED flickering lights (red, yellow, orange) and an exterior LED nano light (yellow). The circuit board is located on a lower-level interior wall and accessed from underneath the building.

**(A) Power Port** 16-20VAC  
power source required

**(B) LED Ports** Maximum current  
30mA each

**(C) Dimmer Controls**  
Lead Cable plugs into Port (A).  
Lights plug into Ports (B). Each  
LED Port has a corresponding  
Dimmer Control (C). Use a  
small slotted or Phillips head  
screwdriver to adjust light  
brightness.



## OPTIONS FOR LIGHTING YOUR BUILDING

### Model Railroad Power Pack

Connect wires on Lead Cable to the accessory terminals on 16-20VAC train power pack.

### Options for Extending Length of Lead Cable

- Use 24AWG wire (not included). Connect wires on Lead Cable to wires on 24AWG cable with electrical tape or wire connectors.
- Discard the Lead Cable and replace it with Connecting Cables (JP5760). Depending on the length of cable needed, Extension Cables (JP5761) can be used with Connecting Cables for an extended reach.

**Just Plug™ Power Supply (JP5770)** *Purchase at your local hobby shop.*  
Unplug Lead Cable from Power Port (A) and insert Power Supply Plug.

*See the complete Just Plug™ Lighting System at [woodlandscenics.com](http://woodlandscenics.com)*